

EASY STEPS **5**



Since 1990

# FIX-IT

# Drill & Fill



## Total Wood Flooring **REPAIR KIT**

— Engineered Hard Wood Floors —

Everything you need in this KIT to repair hollow spots, squeaks, end-lifting, delamination.

No more “bouncy”, “springy”, “creaking”,  
“spongy”, “popping”, “delam” floors!

**Non-Hazardous  
Odor & Solvent  
FREE**

**nwfa**  
National Wood  
Flooring Association  
MEMBER



\* Registered Trademark of Oakline Products, Inc. USA

# Instructions

- 1.** Locate area with hollow spots suspected of delamination (“delam”) of wood floor to plywood/OSB/concrete subfloor. Dropping a golf ball on suspected delam areas and check on bounce back sound differences will indicate location. Mark out suspected areas with painter’s release tapes.
- 2.** Use center punch to mark out spots that need to drill holes. Drill holes at marked spots on floor and ensure it reaches all the way through to the bottom of the wood floor. Vacuum debris from each hole.
- 3.** Stir Deccobond 38 Wood Flooring Adhesive. Fix the large bore Suction Tip (ST) to syringe the Deccobond 38 Wood Flooring Adhesive from the container. Hold in positive pressure & replace tip with Injection Tip ( IT ).
- 4.** Inject Deccobond 38 Wood Flooring Adhesive into hole. If more than one hole is drilled in delam areas, adhesive will exude in the other hole. Fill adhesive in all drilled holes including holes with exuding adhesive.
- 5.** Once voids are filled, use dowels to plug the holes. Dowels are provided with larger diameter; use a sharp blade to taper to good fit. Center punch can be used to assist in a good plug insert.

After plugging, wipe floor with damp cloth & water before adhesive dry up. Dried adhesive film makes cleaning difficult. Top off the plugged holes with wood putty to match the color of the wood floor.

**IMPORTANT:** To ensure that the injection tip and suction tip do not have heavy built up of adhesive after repeated use, immerse tips in large cup of water immediately after each use. Flush the syringe tips with water repeatedly to get a clean tip & save for reuse.

## Each Kit comprises:

- 1 x 500 ml. (1.1 Pint) Deccobond 38, Flooring Adhesive (D 38)
- 1 x 50 ml. Heavy Duty Syringe c/w replacement washers. (S 50)
- 2 x Tips: 1 x Injection Tip (IT 12) & 1 x Suction Tip (ST 8)
- 1 x Drill Bit  $\frac{1}{8}$ ” bore (DB 8)
- 4 x Dowels (DW 4)
- 1 x Center Punch for marking (CP 1)
- 1 x pair Vinyl Gloves (VG 1)

All items in the kit are available for sale separately.

Deccobond 38, Flooring Adhesives (D 38) are available in two sizes: 500 ml. (1.1 Pint) & 4.0 L (1.04 US Gal) jug.

**WARRANTY:** All information are the results of carefully executed investigation. All components & adhesives are sold without warranty, either express or implied since conditions under which these goods are transported, stored, used or applied are beyond our control. User and/or Buyer assume all risks and liability for the results obtained whether used singly or in combination with other products. Our liability for all damages hereunder shall in no case exceed the purchase price of the quantity consumed of the particular shipment with respect to which such damages may be claimed.